

Sikorsky Global Helicopters

A Sikorsky Company

2010 Model S-333 helicopter Overhaul & Retirement Schedule

COMPONENTS WITH SCHEDULED OVERHAUL TIMES	OVERHAUL INTERVAL HOURS
Main Rotor Transmission Tail Rotor Transmission Engine Compressor Turbine-mini Turbine Fuel Pump Fuel Control Power Governor Fuel Nozzle Bleed Valve Starter/Generator	2,200 3,000 3,500 1,750 3,500 4,000 2,500 2,000 2,500 1,500 1,000
COMPONENTS WITH MANDATORY RETIREMENT TIMES	RETIREMENT LIFE HOURS
Aft Fuselage Splice Fitting Engine Drive Adapter Horizontal Stabilizer Assembly KAFLEX Drive Shaft Main Rotor Blade Main Rotor Hub Assembly Main Rotor Shaft Assembly Main Rotor Elastomeric Dampers Main Rotor Mast Main Rotor Pitch Bearing Shaft Main Rotor Thrust Bearing Main Rotor Transmission Carrier Main Rotor Transmission Input Pinion Tailboom Assembly Tail Rotor Drive Shaft Tail Rotor Blade Tail Rotor Blade Retention Straps Vertical Tail Vertical Tail Attach Fittings Belt Drive System Overhaul Upper Ball Bearings, Belt Drive Frame Assembly Lower Ball Bearings, Belt Drive Frame Assembly Idler Pulley Bearings, Belt Drive Assembly	5,200 6,000 8,500 7,600 5,200 7,500 1,600 6,000 13,500 4,000 2,000 4,400 4,400 5,200 18,600 12,000 5,100 13,000 5,200 2,400 2,400 2,400
Reference: Type Certificate Data Sheet #4H12; Revision 26	